

INSTRUCTIONS FOR USE

SINGLE CLOSURE

Press the shackle down onto the wrist and turn the hook until the toothed part fits, tightening as required.

DOUBLE CLOSURE



With the shackle closed on the wrist, press the tip of the key on the side button of the shackle.

In this way, the hook is blocked against movement in any direction.

The manufacturer recommends always using the double closure.

SIMPLE CLOSURE OPENING



Insert the key into the lock and rotate it a quarter turn. Hold in this position while releasing the cuff.

DOUBLE CLOSURE OPENING



Insert the key into the keyhole, then rotate it a half turn in one direction to release the double lock and then a quarter turn in the opposite direction.

Cleaning and lubrication with quality oils is recommended. After lubricating, remove excess oil to avoid slippery surfaces.